

BUILDWELL

BLOCK JOINTING MORTAR

MILAYE
SIRF PAANI
LAGAYE BINA
PARESHAANI®



40 Kg Bag | PACKAGING

Highlights

- ✓ Polymer Modified Pre-Mixed, Only Water to Be Added
- ✓ Prevent Seepage & Water Percolation
- ✓ Excellent Bonding To The AAC Block's
- ✓ Better Levelling

HOW TO APPLY



1 The AAC, Fly Ash & Hollow blocks should be dry, clean and pre-wet before application. Do not apply on a dirty/greasy surface.



2 Add Black Jointing Mortar to water and mix well for 5-10 mins (Recommended mix 23% water.)



3 Allow the mortar to stand for 5 min then remix again for 2 min.



4 Apply the mix on clean, dry block surface with mason's notch trowel to make an even 3-4 mm joint layer.



5 Correction time for Re-alignment is upto 10 minutes to ensure perfection of the block placement.



6 'BuildWell' Block Jointing Mortar is self-curing and does not require water curing post application.



7 'BuildWell' Block Jointing Mortar wall is now ready for plastering application.

KEY FEATURES

- Time & manpower is saved
- Lesser shrinkage & seamless structure
- High strength adhesion
- Consistency of material & quality
- Can be applied by ordinary mason
- No curing is required
- Thinner layer guarantees to be more cost-effective
- Easy to mix and faster to Apply

BJM

ADDITIONAL INFORMATION

TEST	TEST METHOD	SPECIFICATION	RESULTS
Water Demand	IS:4031(Part-4)1988	20-35%	23.5
Setting Time: Initial	IS:4031 (part-5) :1988	> 30 min	360
Setting Time: Final		<=600 min	385

COVERAGE

90 to 100 sqft / Bag

STORAGE

